













## Figure 5

- Base Configuration
  - This can be set now or be a previously surveyed or stored point