

Exporting a Text File with X-PAD Ultimate




Start X-PAD Ultimate and Select your Job.






Select Export & Share



Select Text File (ASCII)



In Parameters Screen


Data = All Points


Scheme = PN-NEX-C (USA)

Separator = Comma (,)

File Extension =.txt


Select Next






You will now see a preview of the points you have selected for Export.

Select Accept



You will now see a Report Screen with the number of Exported Points you have selected.

Select Accept




On the Export & Share Screen you will now be given the options of locations for your Exported Points.


In this example I have chosen to save my text file to the Device/Cloud.

Select Accept


Downloading a Text File to your Computer




Using a Cable (USB to USB-C) connect your device to your computer.




In this example I am using a Mesa 3 tablet so I will navigate to Mesa / Internal Storage.




I will now be taken to the Folder Location on my device. I will now select the X-PAD Folder.



In the X-PAD Folder I will now see my Site Folders. Open your Site Folder or My Site Folder if you have not chosen to create a new site with each project.



Once you have opened your Site Folder select the Export Folder.



You will now see your Exported Text Files where you can Copy or Cut the files from your Device and Paste into your specific Storage Area (File) on your Computer